PUSH BUTTON SWITCH

IRS-2101-1B ON-OFF
DPST 6P
IRS-2102-1B ON-ON
DPDT 6P



IRS-2101-1C ON-OFF
DPST 6P
IRS-2102-1C ON-ON
DPDT 6P



IRS-2101E-1C ON-OFF
DPST 6P



IRS-2101-3C ON-OFF
DPST 6P



PBS-10B OFF-(ON)
(PLASTIC ROD)



PBS-10B-2 OFF-(ON)
PBS-10C-2 ON-(OFF)
(METAL ROD)



PBS-11A ON-OFF
PBS-11B OFF-(ON)
PBS-11C ON-(OFF)



PBS-12A ON-OFF
PBS-12B OFF-(ON)
PBS-12C ON-(OFF)



PBS-13B OFF-(ON)
PBS-13C ON-(OFF)
8A 125VAC; 4A 250VAC



PBS-14A ON-OFF
PBS-14B OFF-(ON)
PBS-14C ON-(OFF)



PBS-15A ON-OFF



PBS-15B OFF-(ON)
PBS-15C ON-(OFF)



PBS-16A ON-OFF
PBS-16B OFF-(ON)
PBS-16C ON-(OFF)



PBS-17A ON-OFF
4A 125VAC;2A 250VAC



PBS-17A-2 ON-OFF



PBS-17A-3 ON-OFF
4A 125VAC; 2A 250VAC



PUSH BUTTON SWITCH

PBS-19B OFF-(ON)
PBS-19C ON-(OFF)
5A 125VAC; 2.5A 250VAC



PBS-26B OFF-ON
PBS-26C ON-(OFF)
4A 125VAC;2A 250VAC



PBS-19B-2 OFF-(ON)
PBS-19C-2 ON-(OFF)
5A 125VAC; 2.5A 250VAC



PBS-27B OFF-(ON)



PBS-19B-3 OFF-(ON)
PBS-19C-3 ON-(OFF)
5A 125VAC; 2.5A 250VAC



ASW-01
20A 12VDC;10A 30VDC
DPDT 5P



PBS-20A ON-OFF
PBS-20B (OFF)-ON
5A 125VAC; 2.5A 250VAC



ASW-02D
20A 12VDC
DPDT 5P(with lamp)



PBS-20A-2 ON-OFF
PBS-20B-2 OFF-(ON)



ASW-03 DPDT 4P
ASW-04 DPDT 5P
20A 12VDC;10A 30VDC



PBS-21A ON-OFF
PBS-21B OFF-(ON)



ASW-05 (L=7,13,20)
6A 30VDC;10A 12VDC
SPST 2P



PBS-22A ON-OFF
PBS-22B OFF-(ON)



ASW-06-101 ON-OFF 2P
ASW-06-102 ON-ON 3P
ASW-06-103 ON-OFF-ON 3P
10A 30VDC;20A 12VDC



PBS-23B OFF-(ON)



ASW-07D ON-OFF
25A 12VDC
SPST 3P(with lamp)